


GENUINE PARTS

INSTALLATION INSTRUCTIONS


Part Number 2 54005 2 54008 1 00891 2 AW000
1 00891
2 AW000
ł
rill Bit



1) Clean shaded area with soap and water mixture and dry.

2) Remove exisiting screws (15mm) and discard.

3) Remove existing lower bolt. Do not discard bolt.



- 4) Align front splash guard to vehicle and loosely install supplied screws 20mm (C) in middle and top holes.
- 5) Loosely re-install lower bolt.

6) While lifting up in area (A) align splash guard edge to side sill protector surface and tighten lower bolt.

NOTE:

Do not over tighten bolt. Reference Tighten Torque: 3.8~4.4N-m {34~39 in-lb}

7) While pushing up and into vehicle in area (B) tighten screws in middle then top hole

NOTE:

Do not over tighten screw. Reference Tighten Torque: 3.8~4.4N-m {34~39 in-lb}

INSTALLATION PROCEDURE: (continue)

Fig. 6

- 8) Mark hole center with awl.
- 9) Drill 1.5mm (1/16") center pilot hole.

NOTE:

Hold splash guard tight to the vehicle while drilling and installing screws to ensure no gap occurs between fender and splash guard.

10) Install supplied screw - DO NOT OVER TIGHTEN

