




GENUINE PARTS



INSTALLATION INSTRUCTIONS



o. KICK Plate Outer KH9. Dashboard Side Lower Panel RH



9. VEHICLE PARTS REMOVAL




Fig 5

Fig 6

9. VEHICLE PARTS REMOVAL

Instrument Side Finisher LH (5)

pawls×3

nylon / removal

tool


11 ht

 $M \wedge$

Instrument Lower Panel LH (6)

Bolts×2

pawls×3



clip

pawlsx3


CMetal 날 clips×4

- 4) Glove Box Lower Cover removal
 - a) Pull downward, disengaged pawls.
 - b) Remove Glove Box Lower Cover (4). Shown in Fig4.


- 5) Repeat steps 1) to 3) for RH side of vehicle. Kick Plate Inner RH (7). Kick Plate Outer RH (8). Dashboard Side Lower Panel RH (9).
- 6) Instrument Side Finisher LH removal
 - a) Insert a nylon remover tool into lower space.
 - b) Pull the Instrument Side Finisher LH crosswise. Shown in Fig5.
 - c) Remove Instrument Side Finisher LH (5).

- 7) Instrument Lower Panel LH removal
 - a) Remove Hood Opener Mounting Bolts.
 - b) Pull downward Instrument Lower Panel LH to disengage pawls and clips. Shown in Fig6.
 - c) Disconnect harness from Instrument Lower Panel LH and hose plug.
 - d) Remove Instrument Lower Panel LH (6).


10. WIRING HARNESS INSTALLATION




10. WIRING HARNESS INSTALLATION CONT'D










- 5) Flip the carpet of the driver's side.
- Route Harness (C) under accelerator pedal bracket, and attach harness to floor using the Flat wire protector (F) shown in Fig10. (4 places)

- 7) Remove one push nut from front passenger side carpet. Shown in Fig11.
- 8) Flip the carpet of passenger side.
- 9) Route fish tape behind center console from driver's side harness to passenger side.
- 10) Pull harness with fish tape behind center console.
- 11) Attach passenger side harness using the Flat wire protector (F) shown in Fig11. (5 places)
- 12) Route Harness (C) through existing vehicle harness protector and attach the Harness (C) to vehicle harness at position shown in Fig 12, using the Tie wrap (D)-(3 places)


10. WIRING HARNESS INSTALLATION CONT'D



13) Route Harness (C) through existing vehicle harness protector and attach the Harness (C) to vehicle harness at the position shown in Fig13, using the Tie wrap (D) - (3 places)

- 14) Function check
 - a) Connect Harness (C) to the lamp unit harness of Kick plate (A) and (B).
 - b) Connect battery.
 - c) Check function. Confirm "INFINITI" text illuminates when either door is open.
 - d) If OK, disconnect Harness (C) from the lamp unit harness of Kick plate (A) and (B).
 - e) If NG, check harness routine, connections and lamp unit to identify root cause and fix it. Repeat steps a) to c) until it is OK.
 - f) Disconnect battery.

KICK PLATE INSTALLATION 11.



The procedure below shows the installation for LH side. Repeat procedure for RH side.

- 1) Remove the vehicle weather strip near the Kick plate (A) attachment location shown in Fig14.
- 2) Clean the attachment area of Kick plate (A) with soapy water.
- 3) Dry area with soft non linting towel.
- 4) Clean area with 50/50 alcohol & water solution and let dry for 30 seconds.
- 5) Remove location a and b double-sided tape's liner shown in Fig15.
- 6) Pull the adhesive tape liner pull tab to partially remove liner from all other locations. Using masking tape, hold the liner to the visible side of the Kick plate (A) surface as shown in Fig15.
- 7) Align pins on part to second and fourth hole on vehicle from front side.
- 8) Set part on vehicle, being careful to keep the outside edge of the part parallel to the rocker panel.
- 9) Gradually remove the tape liner at the back of the Kick plate (A) starting from the front, apply minimum 11lb (49N) of pressure along the part to attach tape to body shown in Fig15.

CAUTION

- Use caution when applying pressure as the surface may dent.
- During installation, be careful not to allow the harness to get stuck between the vehicle and the kick plate.
- Harness should be routed through the notched area of the kick plate.

HARNESS CONNECTION INSTALLATION 12. The procedure below shows the installation for LH side. Repeat procedure for RH side. Kick plate LH (A) Fig 16 ٦٢ 1) Secure harness (C) to vehicle harness at connector FRONT with Tie Wrap (D) as shown in Fig16. (1 place) → Tie wrap (D) 2) Fold one piece Urethane foam tape (E) and cut Excessive lamp Harness into two equal pieces. 3) Clean both sides of the attachment area for the Urethane foam tape (E) with the 50/50 alcohol Kick plate LH (A) Connector & water solution. Let dry for 30 seconds. Shown in Fig16. Lamp Unit Harness 4) Attach the cut piece of Urethane foam tape (E) to vehicle flange as shown in Fig17. Urethane foam tape (E) 5) Place the lamp harness on top of the Urethane (Reference "Detail A") foam tape (E), then apply second half of the Detail A Urethane foam tape (E) on top of the harness. 11 Harness routing of Vehicle Flange FRONT Straight 6) Connect the connectors and apply the Urethane Diagonally foam tape (E) on the connecting section as shown Vehicle Flange in Fig17. Urethane foam tape (E) Lamp Unit 7) Attach excessive lamp harness to the vehicle Harness harness with a Tie wrap (D) as shown in Fig16. (1 place) **OK** NG 8) Cut excessive Tie wrap. Fig 17 Urethane foam tape (E) Lamp Unit Harness Vehicle Flange Connector Urethane foam tape (E) CAUTION • Do not attach the harness to sharp metal edge.

INSTALLATION INSTRUCTIONS - Illuminated Kick Plate

14. CHECK AFTER INSTALLATION

1) Please check that the installation has no problem.

- a) confirm connection of connector
- b) confirm whether wire harness is fixed.

15. FUNCTION CHECK

□ 1) Re-connect battery negative terminal.

- □ 2)Confirm all switch function are working on Instrument Lower Panel LH.
- □ 3) Confirm "INFINITI" text is illuminated when either door is in the opened position. Manual engage door switch to verify Illuminated Kick Plate ON/OFF function is working.

16. REINSTALLATION OF REMOVED PARTS

□ 1)All removed vehicle parts have been reinstalled.

_ T/Air removed vehicle parts have been remstaned.
CAUTION
 Use caution when re-installing interior components to avoid damage, scratch, or breaking of mounting clips.
2)Clean interior of vehicle.
17. VEHICLE CHECK
 Remove all tools from the vehicle. Inspect reinstalled interior trim parts for proper panel fit. Reset radio presets to the recorded setting. Turn ignition to ON position. Confirm proper radio operation. Initialize sun roof, and power window operation. Confirm proper operation of the rear window washer fluid. Confirm the functionality of all four blinkers and hazard warning signal flasher. Confirm the operation of all door lock and unlock using remote key. Reset windows. When window is completely up, continue to hold in up position for 4 seconds. Turn ignition to off position.
 During restoring, please use caution to avoid the pinching or breaking of the vehicle's harness, or damage any other parts.