

GENUINE PARTS

INSTALLATION INSTRUCTIONS

DESCRI	PTION:	Rea	r Spoiler Kit		
APPLIC	ATION:	G se	edan (2010)		
PART N	JMBER:	K60	30-JK6xx (Without rear view camera) (xx Designates col	or)	
			30-1NFxx (With rear view camera) (xx Designates color)		
KIT COM					
Item	Qt JK6xx	ty. 1NFxx	Description	Service Part Number	
А	1	1	Rear Spoiler		
В	1		Inner Bracket		
С	1		Spacer		
D	5	5	Seal		
E	4	4	Tapping Screw M4×12mm		
F	2	4	Tapping Screw M5 × 16mm		
G	4	4	Bolt		
Н	2	2	Clip		
J	1	1	Installation Instructions Replacement Template		
К	1		Template A		
L	1/1	1/1	Template B (RH/LH)		
М	1/1	1/1	Template B (RH/LH)		
E (2)00000	F	(2) 0000000 ED:			
TOOLS REQUIRED:• 8mm Socket & driver• Drill• Masking tape• Phillips Screwdriver• 3mm (1/8") and 8mm (5/16") Drill bit• Tape• Center Punch• Deburring tool• Torque wrench• Clean, lint-free wiping cloth• Rust preventative(P/N 999MP-9G001P)• Clip remover• Air compressor & blow gun• 90% or greater alcohol• Clip remover					
• Dealer	installat	ion Reco	ARNING, CAUTIONS CRITICAL STEPS, and NOTES: mmended. CAUTION when the ambient temperature is above 60°F (15°C).		
		-	the vehicle to a wet environment for 24 hours after insta	alling the Rear Spoiler.	

INSTALLATION PROCEDURE: Fig 1-1 Trunk lid Trunk lid Trunk lid trim bumper assembly Fig 1-2 Measurement this gap Trunk lid bumper Trunk lid bumper nut Trunk lid bumper assembly Fig 2 Wrapping foam Tape Trunk striker Fig 3 Trunk lid bumper assembly (2 locations; reuse) Trunk handle (reuse) Clips (9 locations; reuse) Emergency release Inner trim (reuse)

- 1) Disconnect vehicle battery (negative terminal).
- 2) Open vehicle trunk lid and find trunk lid bumper assemblies (RH/LH: 1 location each)


 Use a small ruler to measure the gap between bottom of trunk lid bumper assembly and top of trunk lid bumper nut (RH/LH 1 location each). Write down measured dimensions in following table.

Trunk lid bumper gap				
RH	LH			
mm	mm			

- 4) Remove rear spoiler A from box, unwrap it, and put it back in box until later in the procedure.
- 5) Attach wrapping foam from rear spoiler A to trunk opening with tape.

NOTE:

- •After removing wrapping foam from rear spoiler, be sure not to scratch the part.
- •Be sure to cover the trunk striker with the drop cloth.
- Remove inner trim clips (9 locations; reuse), trunk lid bumper assembly (2 locations; reuse), trunk handle (reuse) and emergency release (reuse) from trunk lid with a clip remover.
- 7) Remove inner trim from trunk lid.



- Disconnect trunk lid opener switch connector and rear view camera connector (if vehicle is equipped with rear view camera), and remove their grommets.
- 9) If ground wire exists, remove bolt that attaches it to trunk lid.
- Remove nuts that attach chrome trunk lid finisher (4 locations).
- 11) Apply masking tape around chrome trunk lid finisher to prevent scratches.
- 12) Using clip remover, disengage clips (RH and LH) and remove chrome trunk lid finisher.


13) If vehicle is not equipped with rear view camera, remove grommet.


If vehicle has rear view camera

- 14) Remove Screws (4 locations) that attach inner bracket, and remove inner bracket from chrome trunk lid finisher.
- 15) Remove Screws (4 locations) that attach rear view camera and trunk opener switch to innner bracket.

NOTE;

Be careful not to lose rear view camera and trunk opener switch. They will be used again.





Align to edge of holes

Masking

tape


If vehicle doesn't have rear view camera

- 16) Remove screws (4 locations) that attached inner bracket, and remove inner bracket from chrome trunk lid finisher.
- 17) Remove screws (2 locations) that attach trunk opener switch to inner bracket.NOTE;

Be careful not to lose trunk opener switch. They will be used again.

- Align template A to trunk lid and apply masking tape to hold template in place.
- 19) Mark hole position (+) with senter punch.
- 20) Remove masking tape and template A.

- 21) Align template B (LH) to trunk lid and apply masking tape to hold template in place.
- 22) Mark hole position (+) with senter punch.
- 23) Remove masking tape and template B (LH).
- 24) Repeat procedures 21) through 23) using template B (RH) for right hand side installation.
- 25) Fold tabs of template C (LH).
- 26) Align template C (LH) to trunk lid and apply masking tape to hold template in place.
- 27) Mark hole position (+) with senter punch.



- 28) Remove small portion of template C (LH) by tearing template C at slit.
- Repeat procedures 25) through 28) using template C (RH) for right hand side installation.


- Wrap masking tape around 3mm (1/8") and 8mm (5/16") drill bits, approximately 10mm from tip.
- 31) Drill 1/8" (3mm) \rightarrow 5/16" (8mm) holes at 5 marked locations on trunk lid.
- 32) Remove any sharp edges from drilled holes with deburring tool and remove metal shavings from inside trunk lid with air compressor and blowgun.
- 33) Apply rust preventative (P/N 000MP 9G001P) to drilled holes.
- 34) Using a clean, lint free cloth and 90% or greater alcohol, wipe any dirt and oil from around holes where seals D will be applied. Let area dry thoroughly.
- 35) Attach seals D to trunk lid (5 locations).

If vehicle has rear view camera

- 36) Route trunk lid opener switch grommet through inner bracket B hole.
- 37) Assemble trunk lid opener switch to inner bracket B by installing tapping screw M5 × 16mm F.
 NOTE;

Tightening torque; 2.1 to 2.5 N⋅m (18.6 to 22.1 lbf ⋅in)

 Loosely assemble rear view camera to inner bracket B by installing tapping screw M5 × 16mm F.



- 39) Loosely assemble inner bracket B to rear spoiler A by installing tapping screw M4 × 12mm E_o
- 40) Adjust inner bracket until there is consistent gap between rear spoiler A opening and trunk lid opener switch. Tighten inner bracket with tapping screw E. Adjust rear view camera until there is consistent gap between rear spoiler A opening and rear view camera. Tighten rear view camera with tapping screw F.
 NOTE;

Rear view camera tightening torque; 2.1 to 2.5 N⋅m (18.6 to 22.1 lbf·in) Inner bracket tightening torque; 0.8 to 1.0 N⋅m (7.1 to 8.8 lbf·in)

If vehicle doesn't have rear view camera

- 41) Route trunk lid opener switch grommet through inner bracket B hole and spacer C.
- 42) Assemble trunk lid opener switch to inner bracket B by installing tapping screw M5×16mm F through spacer C.

NOTE;

Tightening torque; 2.1 to 2.5 N⋅m (18.6 to 22.1 lbf ⋅in)

- 43) Loosely assemble inner bracket B to rear spoiler A by installing tapping screw M4 \times 12mm E_o
- 44) Align center of switch to center of rear spoiler A hole then tighten inner bracket B.NOTE;

Tightening torque;

0.8 to 1.0 N·m (7.1 to 8.8 lbf·in)


45) Assemble clips H to rear spoiler A.

INSTALLATION PROCEDURE: Fig 8-6 Behind Outside Rear spoiler A Tape liner Masking tape Fig 8-7 Cleaning area Grommet -0 :00 Fig 9-1 Clips H Rear spoiler A 퓨 유 윤 · · · · · · · · · () . Trunk lid opener Rear view camera Holes switch hole grommet hole Fig 9-2 Bolt G

- 46) Remove approximately 20mm of tape liner from double-sided tape on rear spoiler A in direction shown by arrow.
- 47) Fold tape liner pull tabs onto rear spoiler surface and apply masking tape to ensure that pull tabs are accessible.
- 48) Using a clean, lint free cloth and 90% or greater alcohol, wipe any dirt and oil from mounting surface. Let area dry thoroughly.
- 49) If vehicle is not equipped with rear view camera install grommet that was removed in 13).

- 50) Pull rear view camera and trunk lid opener switch grommets through trunk lid holes.
- 51) Align rear spoiler A on trunk lid and engaged rear spoiler A clips H.

- 52) Loosely install rear spoiler A with bolt G from inside of trunk lid.
- 53) Connect trunk lid opener switch connector and rear view camera cnnector (if vehicle is equipped with rear view camera) which are disconnected in 8).
- 54) Connect vehicle battery (negative terminal).
- 55) Confirm operation of trunk lid opener switch and rear view camera.
- 56) Disconnect vehicle battery (negative terminal).



57) Position rear spoiler A equality clearance from aligning line of template C RH and LH.

- 58) Remove tape liner "a" in direction shown by arrow, push forward and apply 15lbs. of pressure 3 times on rear spoiler A from center to outward.
- 59) Remove tape liner in direction shown by arrow, push downward and apply 15lbs. of pressure 3 times on rear spoiler A in order: b-c.
- 60) Remove masking tape and template C RH/LH.
- 61) Tighten bolt G that were loosely installed in 52).
- 62) Connect trunk lid opener switch, rear view camera switch, and attach ground wire that were removed in 8) and 9).
- 63) Reinstall all parts that were labeled reuse, using reverse of removal process.

- 64) Adjust trunk lid bumper assembly by turning trunk lid bumper nut clockwise until gap between bottom of trunk lid bumper and top of trunk lid bumper nut matches gap measured in 3).
- 65) Remove wrapping foam and close trunk lid.
- 66) Connect vehicle battery (nagative terminal).

Rear view camera-equipped vehicle

CAUTION

After completely installing vehicle parts, make sure to do rear view camera calibration.

INSTALLATION PROCEDURE:						
Fig.9-6 Rear spoiler A b b Limit gap a b c d X mm 1.01.51.01.5						
ACCESSORY CHECK:						
Please check that installation has no problem.						
Check gap. See Fig.9-6.						
REINSTALLATION OF REMOVED PARTS						
Re-install all removed vehicle parts. Refer to the vehicle service manual for more details.						
Clean trunk opening of vehicle.						
FINAL INSPECTION:						
Verify re-installed trim parts for proper flush fit						
Verify all clips are fully engaged and locked.						
Verify re-installed trim parts are free from cracks, scratches or stress marks.						
VEHICLE CHECK						
Remove all tools from vehicle.						