

GENUINE PARTS

MAINTENANCE INSTRUCTIONS

DESCRIPTION:	Allov Wheel -	10 v 81 (//3 F	۲١
DESCRIPTION.	WIIOA MITEEL -	12 V 07 (42)	,,

APPLICATION: QX30

PART NUMBER: KE409 5D400B1

SPECIAL INSTRUCTIONS/ NOTES:

A WARNING

- At the time of initial installation, always replace all parts contained in TPMS service kit. Use the following P/N available from your Infiniti dealer: 40700 5DA0B complete TPMS unit. 40770 5DA0B TMPS Service kit. A total of four (4) kits will need to be obtained for a full vehicle set.
- <u>DO NOT</u> re-use TPMS or TPMS components installed on steel wheel TPMS P/N: 40700 5DA0C. Order new complete TPMS. A Total of four (4) TPMS will needed to be obtained for a full vehicle set.
- Service lug nut N5010 5DA1B must be used for this accessory wheel.
- After installation, check for tire clearance and interference between the body and/or suspension parts.
 Do not drive vehicle if interference is found. Tire interference could cause tire failure and lead to an accident and serious injury.
- Failure to apply the proper torque to the lug nuts could cause wheel separation and lead to an accident and serious injury. Re-torque lug nuts to the specified value after 25 miles of driving.
- Use only the recommended tire size, 235/45R19 for this alloy wheel.
- See the tire and loading information label (tire placard) for the recommended COLD tire air pressure.
- The Original Equipment TPMS air valves should be used on the new accessory wheels. If replacement parts are needed, please obtain the following part numbers: Center cap P/N 40342 5DA9C; wheel bolt P/N N5010 5DA1B; TPMS air valve (Complete) P/N 40700 5DA0B; TPMS Service kit 40770 5DA0B.
- For additional tire information, see owner's manual.
- Balance the alloy wheel and tire assembly.
- Place these maintenance instructions in the glove compartment.

REGULAR CLEANING:

- To maintain original appearance, always wash wheels when washing vehicle. Typical road deposits can be corrosive and can harm finish over time. Road film, brake dust and other surface contaminants should be removed on a regular basis.
- · Do not clean hot wheels.

USE OF PROPER CLEANING AGENTS AND TOOLS:
 Use a mild soap and water to clean wheels. Do not use abrasive cleaners. Do not use cleaning agents that contain acids that will permanently stain wheels. A mild degreaser may be used for stubborn stains, but should be removed with water immediately following cleaning process. Do not use scouring pads, steel wool, or metal brushes that can scratch or damage your wheel's finish.
Use a damp soft cloth, sponge, soft brush, or spoke brush. • For additional protection, apply a coat of non-abrasive cream wax on wheels, once your wheels are
clean. Wax is not only to enhance reflectivity, but also to add protective film to wheel to reduce future cleaning effort.